OWNER'S MANUAL

2024 CB500F / CBR500R / NX500

This manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is resold.

This publication includes the latest production information available before printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

The vehicle pictured in this owner's manual may not match your actual vehicle.

Welcome

Congratulations on your purchase of a new Honda vehicle. Your selection of a Honda makes you part of a worldwide family of satisfied customers who appreciate Honda's reputation for building quality into every product.

To ensure your safety and riding pleasure:

- Read this owner's manual carefully.
- Follow all recommendations and procedures contained in this manual.
- Pay close attention to safety messages contained in this manual and on the vehicle.

To protect your investment, we urge you to take responsibility for keeping your vehicle well-serviced and maintained. Also, observe the break-in guidelines and always perform the pre-ride inspection and other periodic checks in this manual. When service is required, remember that your Honda dealer knows your vehicle best. If you have the required mechanical "knowhow" and tools, you can purchase an official Honda Service Manual to help you perform many maintenance and repair tasks. **D** P. 167

Read the warranty information thoroughly so that you understand the warranty coverage and are aware of your rights and responsibilities. ■ P. 168

You may also want to visit our website at www.powersports.honda.com. Canada www.honda.ca. Happy riding!

A Few Words About Safety

Your safety, and the safety of others, is very important. Operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on safety labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a vehicle. You must use your own good judgment.

You will find important safety information in a variety of forms, including:

- Safety labels on the vehicle
- Safety Messages preceded by a safety alert symbol and one of three signal words: DANGER, WARNING, or CAUTION. These signal words mean:

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

ACAUTION

You CAN be HURT if you don't follow instructions.

Other important information is provided under the following titles:

NOTICE Information to help you avoid damage to your vehicle, other property, or the environment.

Contents

Vehicle Safety	P. 2	
Operation Guide	P. 20	
Maintenance	P. 91	
Troubleshooting	P. 134	
Information	P. 148	
Specifications	P. 175	

Vehicle Safety

This section contains important information for safe riding of your vehicle. Please read this section carefully.

Safety Guidelines	P. 3
Safety Labels	
Safety Precautions	
Riding Precautions	P. 14
Accessories & Modifications	P. 18
Loading	P. 19

Safety Guidelines

Follow these guidelines to enhance your safety:

- Perform all routine and regular inspections specified in this manual.
- Stop the engine and keep sparks and flames away before filling the fuel tank.
- Do not run the engine in enclosed or partly enclosed areas. Carbon monoxide in exhaust gases is toxic and can kill you.

Always Wear a Helmet

It's a proven fact: helmets and protective apparel significantly reduce the number and severity of head and other injuries. So always wear an approved helmet and protective apparel. ➡ P. 13

Before Riding

Except NX500

Make sure that you are physically fit, mentally focused, and free of alcohol and drugs. Check that you and your passenger are both wearing an approved helmet and protective apparel. Instruct your passenger on holding onto the seat strap or your waist, leaning with you in turns, and keeping their feet on the footpegs, even when the vehicle is stopped.

NX500

Make sure that you are physically fit, mentally focused, and free of alcohol and drugs. Check that you and your passenger are both wearing an approved helmet and protective apparel. Instruct your passenger on holding onto the grab rails or your waist, leaning with you in turns, and keeping their feet on the footpegs, even when the vehicle is stopped.

Take Time to Learn & Practice

Even if you have ridden other vehicles, practice riding in a safe area to become familiar with how this vehicle works and handles, and to become accustomed to the vehicle's size and weight.

We recommend that all riders take a certified course approved by the Motorcycle Safety Foundation (MSF) or a state approved training course. New riders should start with the basic course, and even experienced riders will find the advanced course beneficial.

For information about the MSF training course nearest you, call the national toll-free number: (800) 446-9227.

USA Other riding tips can be found in the You and Your Motorcycle Riding Tips booklet that came with your vehicle.

Ride Defensively

Always pay attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

Make Yourself Easy to See

Make yourself more visible, especially at night, by wearing bright reflective clothing, positioning yourself so other drivers can see you, signaling before turning or changing lanes, and using your horn when necessary.

Ride within Your Limits

Never ride beyond your personal abilities or faster than conditions warrant. Fatigue and inattention can impair your ability to use good judgment and ride safely.

Don't Drink or Use Drugs and Ride

Alcohol or drugs and riding don't mix. Even one alcoholic drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. The same is true for drug use. Don't drink or use and ride, and don't let your friends do it either.

Keep Your Honda in Safe Condition

It's important to keep your vehicle properly maintained and in safe riding condition. Inspect your vehicle before every ride and perform all recommended maintenance. Never exceed load limits (E) P. 19), and do not modify your vehicle or install accessories that would make your vehicle unsafe (E) P. 18).

If You are Involved in a Crash

Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first turn the ignition switch to the OFF position, and evaluate the condition of your vehicle. Inspect for fluid leaks, check the tightness of critical nuts and bolts, and check the handlebar, control levers, brakes, and wheels. Ride slowly and cautiously. Your vehicle may have suffered damage that is not immediately apparent. Have your vehicle thoroughly checked at a qualified service facility as soon as possible.

Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colorless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in a confined or even partly enclosed area, the air you breathe could contain a dangerous amount of carbon monoxide.

Never run your vehicle inside a garage or other enclosure.

AWARNING

Running the engine of your vehicle while in an enclosed or even partially enclosed area can cause a rapid buildup of toxic carbon monoxide gas.

Breathing this colorless, odorless gas can quickly cause unconsciousness and lead to death.


Only run your vehicle's engine when it is located in a well ventilated area outdoors.

Safety Labels

Safety Labels

Safety and information labels on your vehicle provide important safety information and may warn you of potential hazards that could cause serious injury. Read these labels carefully and don't remove them.

If a label comes off or becomes hard to read, contact your dealer for a replacement.





A WARNING

Improper loading can cause a crash and you may be seriously hurt or killed. See "Load Limits and Guidelines" in your Owner's Manual for complete instructions.
 For your protection, always wear your helmet while riding. Read the owner's manual carefully.


 Image: the pressure of the protection of the pressure of the pressu


Safety Labels





Safety Labels





Safety Precautions

- Ride cautiously and keep your hands on the handlebar and feet on the footpegs.
- Except NX500

Instruct your passenger to keep their hands on the seat strap or your waist and their feet on the footpegs while riding.

• NX500

Instruct your passenger to keep their hands on the grab rails or your waist and their feet on the footpegs while riding.

• Always consider the safety of your passenger, as well as other drivers and riders.

Protective Apparel

Make sure that you and any passenger are wearing an approved helmet, eye protection, and high-visibility protective clothing. Avoid wearing loose clothes that could get caught on any part of the vehicle. Ride defensively in response to weather and road conditions.

Helmet

Should be safety-standard certified, highvisibility, and the correct size for your head.

- Must fit comfortably but securely, with the chin strap fastened
- Face shield with unobstructed field of vision or other approved eye protection

USA Look for a DOT (Department of Transportation) certification label on any helmet you buy.

AWARNING

Not wearing a helmet increases the chance of serious injury or death in a crash.

Make sure that you and any passenger always wear an approved helmet and protective apparel.

Gloves

Full-finger leather gloves with high abrasion resistance

Boots or Riding Shoes

Sturdy boots with non-slip soles and ankle protection

Jacket and Pants

Protective, highly visible, long-sleeved jacket and durable long pants for riding (or a protective suit)

Riding Precautions

Break-in Period

During the first 300 miles (500 km) of running, follow these guidelines to ensure your vehicle's future reliability and performance.

- Avoid full-throttle starts and rapid acceleration.
- Avoid hard braking and rapid down-shifts.
- Ride conservatively.

Brakes

Observe the following guidelines:

- Avoid excessively hard braking and downshifting.
 - Sudden braking can reduce the vehicle's stability.
 - Where possible, reduce speed before turning; otherwise you risk sliding out.

- Exercise caution on low traction surfaces.
 - The tires slip more easily on such surfaces and braking distances are longer.
- Avoid continuous braking.
 - Repeated braking, such as when descending long, steep slopes can seriously overheat the brakes, reducing their effectiveness. Use engine braking with intermittent use of the brakes to reduce speed.
- For full braking effectiveness, operate both the front and rear brakes together.

Anti-lock Brake System (ABS)

This model is equipped with an Anti-lock Brake System (ABS) designed to help prevent the brakes from locking up during hard braking.

- ABS does not reduce braking distance. In certain circumstances, ABS may result in a longer stopping distance.
- ABS does not function at speeds below 6 mph (10 km/h).

- The brake lever and pedal may recoil slightly when applying the brakes. This is normal.
- Always use the recommended front/rear tires and sprockets to ensure correct ABS operation.

Engine Braking

Engine braking helps slow your vehicle down when you release the throttle. For further slowing action, downshift to a lower gear. Use engine braking with intermittent use of the brakes to reduce speed when descending long, steep slopes.

Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

Riding Precautions

Parking

- Park on a firm, level surface.
- If you must park on a slight incline or loose surface, park so that the vehicle cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
- To reduce the likelihood of theft, always lock the handlebar and remove the key when leaving the vehicle unattended.
 Use of an anti-theft device is also recommended.

Parking with the Side Stand

- 1. Stop the engine.
- 2. Push the side stand down.
- **3.** Slowly lean the vehicle to the left until its weight rests on the side stand.

- 4. Turn the handlebar fully to the left.
 - Turning the handlebar to the right reduces stability and may cause the vehicle to fall.

Refueling and Fuel Guidelines

Follow these guidelines to protect the engine, fuel system and catalytic converter:

- Use only unleaded gasoline.
- Use the recommended octane number. Using lower octane gasoline will result in decreased engine performance.
- Do not use fuels containing a high concentration of alcohol. ▶ P. 166
- Do not use stale or contaminated gasoline or an oil/gasoline mixture.
- Avoid getting dirt or water in the fuel tank.

Honda Selectable Torque Control

When the Honda selectable torque control (Torque Control) detects rear wheel spin during acceleration, the system will limit the amount of torque applied to the rear wheel.

Torque Control does not work during deceleration and will not prevent the rear wheel from skidding due to engine braking. Do not close the throttle suddenly, especially when riding on slippery surfaces. Torque Control may not compensate for rough road conditions or rapid throttle operation. Always consider road and weather conditions, as well as your skills and condition, when applying throttle.

If your vehicle gets stuck in mud, snow, or sand, it may be easier to free it by turning off the Torque Control temporarily.

Temporarily turning off Torque Control also may help you maintain control and balance when riding on off-road terrain.

Always use the recommended tires and sprockets to ensure correct Torque Control operation.

Accessories & Modifications

We strongly advise that you do not add any accessories that were not specifically designed or approved for your vehicle by Honda or make modifications to your vehicle from its original design. Doing so can make it unsafe. Modifying your vehicle may also void your warranty and make your vehicle illegal to operate on public roads. Before deciding to install accessories on your vehicle, be certain the modification is safe and legal.

AWARNING

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Do not pull a trailer with, or attach a sidecar to, your vehicle. Your vehicle was not designed for these attachments, and their use can seriously impair your vehicle's handling.

Loading

- Carrying extra weight affects your vehicle's handling, braking and stability. Always ride at a safe speed for the load you are carrying.
- Avoid carrying an excessive load and keep within specified load limits.

Maximum weight capacity / Maximum luggage weight ₽ P. 175

- Tie all luggage securely, evenly balanced, and close to the center of the vehicle.
- Do not place objects near the lights or the muffler.


AWARNING

Overloading or improper loading can cause a crash and you can be seriously hurt or killed.


Follow all load limits and other loading guidelines in this manual.

Parts Location

CB500F




- Tool kit P.88
- Document bag P.89
- Front brake fluid reservoir
- Front brake lever
 P.132
- Throttle grip P.131
- Rear brake fluid reservoir P.123 Engine oil fill cap
- Brake light switch P.125 Engine oil level inspection window
- Rear brake pedal




Continued 21

Parts Location (Continued)


CBR500R






Parts Location (Continued)

NX500






Instruments

You can change the speed and mileage, and fuel mileage meter units. P.43 P.57




Do not operate the display functions for a long time with the engine stopped. It may result in a low (or dead) battery.



Continued 27

Instruments (Continued)

Speedometer/Tachometer/Fuel gauge/Gear position indicator




This meter has three display types.

The display and arrangement of speedometer, tachometer, and INFO area change depending on each display type.


▶ The tachometer is not displayed when select the SIMPLE type display.

To change the display type: P.43 P.50



Instruments (Continued)

Status bar



INFO area


The INFO area displays various vehicle information.

The following items are displayed by default.

- Odometer [TOTAL]
- Current fuel mileage [INST. CONS.]
- Tripmeter A [TRIP A]
- Tripmeter B [TRIP B]


The information item displayed in the INFO area can be changed arbitrarily. Up to 10 items are available. (Including Blank) If no item is selected or only Blank is selected, the INFO area has no items.

To change the information: P.43




Instruments (Continued)

The types of information item that can be displayed in the INFO area are as follows:



Odometer [TOTAL]

Total distance ridden.



When "-----" is displayed, go to your dealer for service.

Current fuel mileage [INST. CONS.]

Displays the instantaneous fuel mileage as a bar graph.

AC, II AC, III AC type

Display range: 0 to 100 mile/gal (4 L/100 km or 40 km/L)

CM, II CM, III CM type

Display range: 0 to 4 L/100 km (40 km/L or 100 mile/gal)


• When your speed is less than 3 mph (5 km/h): "zero segment " is displayed.

When "zero segment " is displayed, except for the above-mentioned cases, go to your dealer for service.

Instruments (Continued) Tripmeter A [TRIP A]

Distance ridden since the tripmeter A was reset.

тгіра 12



When "----.-" is displayed, go to your dealer for service.

To reset the tripmeter A: P.39



Tripmeter A fuel consumption [CONS.A]

Displays the tripmeter A fuel consumption since the tripmeter A was reset.

AC, II AC, III AC type Display range: 0.0 to 299.9 gal (L)

CM, II CM, III CM type

Display range: 0.0 to 299.9 L (gal)

CONS.A 2.8 gal $\widehat{\ }$

When "---.-" is displayed go to your dealer for service.

Tripmeter A fuel consumption is reset when you reset tripmeter A.

To reset the tripmeter A: <> P.39



Tripmeter A average fuel mileage [AVG CONS. A]

Displays the average fuel mileage since the tripmeter A was reset.

The average fuel mileage will be calculated based on the value on tripmeter A.


AC, II AC, III AC type

Display range: 0.0 to 299.9 mile/gal (L/100 km or km/L)

CM, II CM, III CM type

Display range: 0.0 to 299.9 L/100 km (km/L or mile/gal)

- Above 299.9 L/100km : "--.-" is displayed.
- Above 299.9 km/L (mile/gal) : "299.9" is displayed.
- When the average fuel mileage is reset: "---.-" is displayed.



When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.

Tripmeter A average fuel mileage is reset when you reset tripmeter A.

To reset the tripmeter A: <->P.39



Instruments (Continued) Tripmeter B [TRIP B]

Distance ridden since the tripmeter B was reset.

TRIP B



When "----.-" is displayed, go to your dealer for service.

To reset the tripmeter B: P.39

►P.42

Tripmeter B fuel consumption [CONS.B]

Displays the tripmeter B fuel consumption since the tripmeter B was reset.

AC, II AC, III AC type Display range: 0.0 to 299.9 gal (L)

CM, II CM, III CM type

Display range: 0.0 to 299.9 L (gal)



When "---.-" is displayed go to your dealer for service.

Tripmeter B fuel consumption is reset when you reset tripmeter B.

To reset the tripmeter B: P.39



Tripmeter B average fuel mileage [AVG CONS. B]

Displays the average fuel mileage since the tripmeter B was reset.

The average fuel mileage will be calculated based on the value on tripmeter B.


AC, II AC, III AC type

Display range: 0.0 to 299.9 mile/gal (L/100 km or km/L)

CM, II CM, III CM type

Display range: 0.0 to 299.9 L/100 km (km/L or mile/gal)

- Above 299.9 L/100km : "--.-" is displayed.
- Above 299.9 km/L (mile/gal) : "299.9" is displayed.
- When the average fuel mileage is reset: "---.-" is displayed.



When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.

Tripmeter B average fuel mileage is reset when you reset tripmeter B.

To reset the tripmeter B: P.39



Instruments (Continued)

Average speed [AVG SPEED] Displays average speed since the engine was

started.

AC, II AC, III AC type

Display range: 0 to 186 mph (0 to 299 km/h)

CM, II CM, III CM type

Display range: 0 to 299 km/h (0 to 186 mph)

- Initial display: "---" is displayed.
- When your vehicle has traveled less than 0.12 mile (0.2 km) since the engine was started: "---" is displayed.
- When your vehicle operating time is less than 16 seconds since the engine was started: "---" is displayed.

AVG SPEED 25 mph

When "---" is displayed except for the abovementioned cases, go to your dealer for service.

Blank display


Display the blank.

 $\widehat{}$

General Menu


To select the general menu, press \blacktriangleright on the sel switch

► If pop-up information displayed, pushing either the ▲ ▼ ● on the sel switch, to hide the pop-up information



You can select the following:

- Status mode
- Trip reset mode
- Setting mode




Instruments (Continued) Status mode

The Status mode displays various vehicle information.

The Status mode has four pages and displays two pieces of information on each page.

Press on the sel switch while select the status mode, display moves to vehicle information page.



The information item displayed in the status mode can be changed arbitrarily.

To change the information: P.43



To switch the information page

To change the information page, press \blacksquare or \blacksquare on the sel switch.





To change the information: P.43 P.53

Continued 41

Instruments (Continued) Trip reset mode

You can reset the tripmeter A or tripmeter B.

- 1. Select the trip reset mode. P.39
- **2.** Press \triangleright on the sel switch.



Select the A or B by pressing the ▼ or
 A on the sel switch.



 Press and hold the ▶ on the sel switch. The tripmeter A or B is reset.




Also, the tripmeter A, tripmeter A fuel consumption and tripmeter A average fuel mileage are automatically reset when the fuel gauge segment increases by 2 or more after refueling and riding your vehicle for 0.06 mile (0.1 km). You can activate or deactivate the automatic reset mode. **P.43 P.49**

Setting mode

To shift to the setting mode

- 1. Select the general menu. -P.39
- 2. Select the setting mode. P.39
- 3. Press 🕨 on the sel switch, and then display moves to the setting mode.
 - Operation while driving is prohibited.

Ordinary display




Setting mode


To return to the ordinary display

- Press \blacksquare on the sel switch until return to the ordinary display.
- Turn the ignition switch to the OFF position, and then to the ON position again.


Instruments (Continued)








Instruments (Continued)





- ▶ Press ▶ on the sel switch
- Press on the sel switch
- Press
 on the sel switch
- **Press on the sel switch**


Instruments (Continued) SHIFT POINT

(On) / O (Off):You can activate or deactivate the shift up mode.

SHIFT POINT : You can change the engine revolutions at which the tachometer start blinking in the shift up mode.

Shift up mode: P.71


Select the I (On) or ○ (Off) using ▲ or ▼ on the sel switch.



2 When select the (On)

Press \blacktriangleright on the sel switch to select the desired setting using \blacktriangle or \bigtriangledown on the sel switch.

Press on the sel switch to complete the setting.



When select the ${f O}$ (Off)


Press on the sel switch to complete the setting.

3 Return to the ordinary display to complete the setting. **>P.43**

To continue setting, press \blacksquare on the sel switch to return to the upper hierarchy.


TRIP A AUTO RESET

You can enable or disable the tripmeter A automatic reset mode.



- Press on the sel switch to complete the setting.
- 3 Return to the ordinary display to complete the setting. ← P.43

To continue setting, press on the sel switch to return to the upper hierarchy.




Instruments (Continued) DISPLAY TYPE

You can change the display type. P.28

 Select the display type ("BAR", "CIRCLE" or "SIMPLE") using ▲ or ▼ on the sel switch.
 Press ◀ on the sel switch to complete the setting.

To continue setting, press \blacksquare on the sel switch to return to the upper hierarchy.




BRIGHTNESS

You can adjust the backlight brightness to one of the eight levels or select the auto adjustment.

Automatic brightness control: P151

The display can become dark when the display is very hot. If it does not restore the original brightness, contact your dealer.

Select the "AUTO" or "MANUAL" using or ▼ on the sel switch.



2 When select the "AUTO"

Press \blacksquare on the sel switch to complete the setting.

When select the "MANUAL"

Press \blacktriangleright on the sel switch to select the backlight brightness using \blacktriangle or \bigtriangledown on the sel switch.

Press on the sel switch to complete the setting.



Return to the ordinary display to complete the setting.
 P.43
 To continue setting, press
 on the sel switch to return to the upper hierarchy.

Instruments (Continued) BACKGROUND

You can change the setting of the background to one of the two colors or select the auto adjustment.

- Operation Guide
- Select the background color using ▲ or ▼ on the sel switch.
- Press on the sel switch to complete the setting.



FAVORITE INFORMATION

You can change the information items displayed in the INFO area and status mode.

1 line information


You can change the information items displayed in the INFO area. **P.31 1 line information setting: P.54**

2 line information

You can change the information items displayed in the information page of status

mode. **P.40**

2 line information setting: <->P.55




Select the 1 line or 2 line information using \frown or \bigtriangledown on the sel switch.

Press \blacktriangleright on the sel switch, display moves to the 1 line or 2 line information setting.


Instruments (Continued) 1 line information setting

1 line information setting **1** Select the 1 or 2 using \blacktriangle or \bigtriangledown on the sel

switch.




2 Press D on the sel switch to select the information items.




- 3 Select the desired information setting using
 - \land or \checkmark on the sel switch.
- Press ▶ on the sel switch, set the information item.
 - Items that have already been set are displayed with a green cursor.
 - Up to 10 items are available. (Including BLANK)
- Seturn to the ordinary display to complete the setting. →P.43

To continue setting, press \blacksquare on the sel switch to return to the upper hierarchy.



3 Select the upper or lower row using \frown or \bigtriangledown on the sel switch.



- Press on the sel switch to select the information items.
- Select the desired information item using ▲ or ▼ on the sel switch.



Instruments (Continued)

6 Return to the ordinary display to complete

the setting. P.43

To continue setting, press \blacksquare on the sel switch to return to the upper hierarchy.

DATE & TIME

- 2 Select the desired setting using ▲ or ▼ on the sel switch.

3 Return to the ordinary display to complete

the setting. P.43

To continue setting, press \triangleleft on the sel switch to return to the upper hierarchy.

▶ The set value is retained.


O mph	SETTING		12:34
Ĵ JAN	2020 12 : 3	24 12	AM PM
	DATE&TIME		

Setting range Date: 1 to 31 Month: JAN to DEC Year: 2020 to 2099 Hour: 0 to 23 Minute: 00 to 59 24/12: 24 or 12 AM/PM: AM or PM

UNIT

You can change the speed and mileage, and fuel mileage meter units.

- Select the "SPEED" or "FUEL CONS." using
 - \blacktriangleright or \triangleleft on the sel switch.
- 2 Select the desired setting using ▲ or ▼ on the sel switch.
- 3 Return to the ordinary display to complete the setting. ←>P.43
 - To continue setting, press on the sel switch to return to the upper hierarchy.
 - The set value is retained.



If you want to select "L/100km" or "km/L" for fuel consumption, "km/h" must be selected in the "SPEED" menu in advance.

When "mph" for speed is selected, "mile/gal" can be selected.

Instruments (Continued)

Changes the system language.

1	Select the 1 or 2 using] or	on	the	sel
	switch.				

0 mph	SETTING	\triangle	12:34
1 DEUTSCH			
2 ENGLISH			
ESPAÑOL			
FRANÇAIS			
ITALIANO			
PORTUGUÊS			
	LANGUAGE		



0,	nph	SETTING	\triangle	12:34
1	DEUTSCH			>
2	ENGLISH			
	ESPAÑOL			
	FRANÇAIS			
	ITALIANO			
	PORTUGUÊS			
		LANGUAGE		

- 3 Select the language using ▲ or ▼ on the sel switch.
- Press ▶ on the sel switch to select the language.
 - Items that have already been set are displayed with a green cursor.
- S Return to the ordinary display to complete

the setting. P.43

To continue setting, press on the sel switch to return to the upper hierarchy.

RESTORE DEFAULT

The set values can be returned to the default settings.


Select the "NO" (not restore) or "YES" (restore) using the ▶ or ◄ on the sel switch.

2 When the "NO" is selected

Press the < on the sel switch. The set value is maintained, and then the display returns to the upper level hierarchy.

When the "YES" is selected

Press and hold the \blacktriangleright on the sel switch. The set value return to default setting.



The following items are restored to their default values:


- DISPLAY TYPE
- SHIFT POINT
- BRIGHTNESS
- BACKGROUND
- FAVORITE INFORMATION
 - The page of the currently selected INFO area and status mode are also initialized.
- UNIT
- LANGUAGE
- TRIP A AUTO RESET

Instruments (Continued) MAINTENANCE

You can select the following:

- PERIODIC MAINTENANCE
 P.61
- OIL CHANGE P.63
- BATTERY VOLTAGE
 P.66
- WATER TEMP P.66
- WARNING INFO -P.67


0 n	nph SETTING 🔝 12:34			
1	PERIODIC MAINTENANCE			
	OIL CHANGE			
	BATTERY VOLTAGE			
	WATER TEMP			
	WARNING INFO			
MAINTENANCE				



PERIODIC MAINTENANCE

You can check the next periodic inspection time.

You can program a reminder for the next periodic inspection time.



Display range:

Distance:

AC, II AC, III AC type

-----, 4,000 to -99,999 mile (6,400 to -99,999 km)

CM, II CM, III CM type

-----, 6,400 to -99,999 km (4,000 to -99,999 mile)


▶ Pass 0 mile (0 km): "-" mark is displayed.

Date:

Month: ---, JAN to DEC Year: ----, 2020 to 2099

Instruments (Continued) Next inspection setting

 Select the distance, month or year using ► or
 on the sel switch.



- 2 Select the desired setting using ▲ or ▼ on the sel switch.
 - ► If you press and hold ▲ on the sel switch while setting the distance, it will move every 1000.

- Available setting range of the distance:
 - AC, II AC, III AC type

------, 100 to 4,000 mile (100 to 6,400 km) Initial setting:-----

CM, II CM, III CM type


-----, 100 to 6,400 km (100 to 4,000 mile) Initial setting:-----

- Available setting range of the date: Month:---, JAN to DEC Initial setting:---Year: ----, 2020 to 2099 Initial setting:----
- Maintenance information (P.69) will not be displayed if the distance and date are set to the initial settings.
- 3 Return to the ordinary display to complete the setting. →P.43

To continue setting, press \triangleleft on the sel switch to return to the upper hierarchy.

OIL CHANGE

You can check the next engine oil change. You can program a reminder for the next engine oil change.



Display range:

Distance:

AC, II AC, III AC type

-----, 8,000 to -99,999 mile (12,800 to -99,999 km)

CM, II CM, III CM type

-----, 12,800 to -99,999 km (8,000 to -99,999 mile)


▶ Pass 0 mile (0 km): "-" mark is displayed.

Date:

Month: ---, JAN to DEC Year: ----, 2020 to 2099

Instruments (Continued) Next oil change setting

 Select the distance, month or year using ► or
 on the sel switch.



- 2 Select the desired setting using ▲ or ▼ on the sel switch.
 - If you press and hold a on the sel switch while setting the distance, it will move every 1000.

Available setting range of the distance:

AC, II AC, III AC type

-----, 100 to 8,000 mile (100 to 12,800 km) Initial setting:-----

CM, II CM, III CM type


-----, 100 to 12,800 km (100 to 8,000 mile) Initial setting:-----

- Available setting range of the date: Month:---, JAN to DEC Initial setting:---Year: ----, 2020 to 2099 Initial setting:----
- Maintenance information (P.69) will not be displayed if the distance and date are set to the initial settings.

When reaching any of the following, the pop-up information is appears in the ordinary display.

- "300 mile" ("500 km") from the next periodic inspection.
- "60 mile" ("100 km") from the next engine oil change.
- One month before the set month.

Periodic inspection



Oil change information


Instruments (Continued) BATTERY VOLTAGE

Displays the current voltage.

0	iph SET	TING	\triangle	12:34
1	PERIODIC MAINTENA	ANCE		
	OIL CHANGE			
	BATTERY VOLTAGE		12.6	
	WATER TEMP		12.0	v
	WARNING INFO			
	MAINT	ENANCE		

WATER TEMP

Displays the current coolant temperature.




If the segment H flashes and warning indicator turned on. P.136

Operation Guide

WARNING INFO

Displays a current maintenance information and (or) warning information. **P.69** If your vehicle has warning information, have your vehicle inspected by your dealer as soon as possible.



Maintenance information

EQUIPMENT

"EQUIPMENT" is displayed but not selectable.



Instruments (Continued) SYSTEM INFORMATION

Displays the softwear version and hardware information.

0 n	ph SETTING	12:34	
	SOFTWARE VERSION	431A03B00C03	
	HARDWARE INFOMATION		
SYSTEM INFOMATION			

Pop-up information

In the following cases, pop-up information is displayed at the INFO area.

• Maintenance information:

When the inspection time of your vehicle is approaching.

• Warning information:

When your vehicle has warning information.


When your vehicle has multiple pieces of information, pop-up information display appears alternately.

Maintenance Information

Indication	Explanation	Remedy
	When the periodic inspection time of your vehicle is approaching.	Have your vehicle inspected by your dealer.
$ \begin{array}{c} & & & \\ & $	When the oil change time of your vehicle is approaching.	Change the engine oil.

Instruments (Continued)

Warning Information



You can hide the pop-up information by pushing either the \blacktriangle \bigtriangledown sel switch while the pop-up information is displayed.

Tachometer color function

Shift Up Mode

When shift up mode is (On), the tachometer color changes according to the shift point setting.

To set the shift up mode P.43



The tachometer blinks when the engine revolutions exceeds the set value of SHIFT POINT.

Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.

Refer to the "Instruments" about indicators appeared on the display: >P.30, >P.70



Left turn signal indicator

Neutral indicator

Comes on when the transmission is in Neutral.

⇒ Right turn signal indicator

Comes on briefly when the ignition switch is turned to the ON position.

If it comes on or flashes while engine is running: **P.138**

ABS (Anti-lock Brake System) indicator

- Comes on when the ignition switch is turned to the ON position.
- Goes off when your speed reaches approximately 6 mph (10 km/h).

If it comes on while riding: P.139

r Torque Control indicator

- Comes on when the ignition switch is turned to the ON position. Goes off when your speed reaches approximately 3 mph (5 km/h) to indicate Torque Control is ready to work.
- Blinks when Torque Control is operating.


If it comes on while riding: P.140




Comes on when the Torque Control is turned Off.

Switches


CB500F






Switches (Continued)

NX500




Left handlebar switches



►P.80

Switches (Continued) Right handlebar switches



Engine stop switch

Should normally remain in the \bigcirc (Run) position.

 \blacktriangleright In an emergency, switch to the \bigotimes (Stop) position (the starter motor will not operate) to stop the engine.

A Hazard switch

Switchable when the ignition switch is in the ON position.

③ Start button

ON

Turns electrical system on for starting/riding.

Ignition Switch

Switches the electrical system on/off, locks the steering.


Key can be removed when in the OFF or LOCK position.



Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



Locking

1 Turn the handlebar all the way to the left.

- 2 Push the key down, and turn the ignition switch to the LOCK position.
 - Jiggle the handlebar if the lock is difficult to engage.
- 3 Remove the key.

Unlocking

Insert the key, push it in, and turn the ignition switch to the OFF position.


Honda Selectable Torque Control

Torque Control (engine power control) can be turned on/off.

- Do not operate the Torque Control switch while riding.
 - Stop the vehicle first and turn the Torque Control off or on.
- The Torque Control cannot be turned off when the system is activated (Torque Control indicator flashing).
- Each time the ignition switch is turned to the ON position, the Torque Control will automatically be set to on.

Torque Control on and off


Torque Control can be turned on and off by pressing and holding the Torque Control switch.




Starting the Engine


Start your engine using the following procedure, regardless of whether the engine is cold or warm.

CB500F



CBR500R





NOTICE

- If the engine does not start within 5 seconds, turn the ignition switch to the OFF position and wait 10 seconds before trying to start the engine again to recover battery voltage.
- Extended fast idling and revving the engine can damage the engine and the exhaust system.
- Snapping the throttle or fast idling for more than about 5 minutes may cause exhaust pipe discoloration.
- The engine will not start if the throttle is fully open.


Starting the Engine (Continued)

Make sure the engine stop switch is in the O (Run) position.

2 Turn the ignition switch to the ON position.
3 Shift the transmission to Neutral (N indicator comes on). Alternatively, pull in the clutch lever to start your vehicle with the transmission in gear so long as the side stand is raised.

- Press the start button with the throttle completely closed.
 - If you cannot start the engine, open the throttle slightly (about 0.1 in (3 mm), without freeplay) and press the start button.

About 0.1 in (3 mm), without freeplay




If the engine does not start:

- ① Open the throttle fully and press the start button for 5 seconds.
- 2 Repeat the normal starting procedure.
- (3) If the engine starts, open the throttle slightly if idling is unstable.
- (4) If the engine does not start, wait 10 seconds before trying steps (1) & (2) again.

If Engine Will Not Start P.135

Shifting Gears

Your vehicle transmission has 6 forward gears in a one-down, five-up shift pattern.



If you put the vehicle in gear with the side stand down, the engine will shut off.

Recommended Shift Points

Shifting Up

From 1st to 2nd	12 mph (20 km/h)
From 2nd to 3rd	19 mph (30 km/h)
From 3rd to 4th	25 mph (40 km/h)
From 4th to 5th	31 mph (50 km/h)
From 5th to 6th	37 mph (60 km/h)


Shifting Down

From 6th to 5th	28 mph (45 km/h)
From 5th to 4th	22 mph (35 km/h)
From 4th to 3rd	16 mph (25 km/h)

NOTICE

Improper shifting can damage the engine, transmission, and drive train. Also, coasting or towing the vehicle for long distances with the engine off can damage the transmission.

Refueling



Do not fill with fuel above the level plate.

Fuel type: Unleaded gasoline only Recommended fuel octane number:

Pump Octane Number (PON) 86 or higher.

Except NX500

Tank capacity: 4.52 US gal (17.1 L)

Tank capacity: 4.62 US gal (17.5 L)

Refueling and Fuel Guidelines -P.16

Opening the Fuel Fill Cap

Open the lock cover, insert the ignition key, and turn it clockwise to open the cap.

Closing the Fuel Fill Cap

- After refueling, push the fuel fill cap closed until it locks.
- 2 Remove the key and close the lock cover.
 - The key cannot be removed if the cap is not locked.

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flames away.
- Only handle fuel outdoors.
- Wipe up spills immediately.


This page intentionally left blank.

Storage Equipment

Helmet Holder

Except NX500

The helmet holders are located underside of the rear seat.




▶ Use the helmet holder only when parked.

Removing the Rear Seat P.115

NX500

The helmet holder is located under the seat. A helmet set wire is in the tool kit.



▶ Use the helmet holder only when parked.

Removing the Seat P.116

AWARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.

Storage Equipment (Continued)

Tool Kit

Except NX500


The tool kit is located under the rear seat.



Removing the Rear Seat >P.115

NX500

The tool kit is located under the seat.



Removing the Seat P.116

Document Bag

Except NX500

The document bag is located underside of the front seat.


Document bag

Removing the Front Seat P.114

NX500

The document bag is located underside of the seat.







Storage Equipment (Continued) Luggage Tie-Down Hooks

Except NX500

The luggage tie-down hooks is located on the underside of the rear seat.





Never use the tie-down hooks to tow or lift the vehicle.

Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data. An optional larger tool kit may be available. Check with your Honda dealer's parts department.

Importance of Maintenance Maintenance Schedule Maintenance Record Maintenance Fundamentals Removing & Installing Body	P. 94 P. 97
Components	P. 112
Battery	P. 112
Clip	
Front Seat	P. 114
Rear Seat	P. 115
Seat	P. 116
Left Side Cover	P. 117
Engine Oil	P. 119
Coolant	

Brakes	P. 123
Side Stand	P. 126
Drive Chain	P. 127
Clutch	P. 128
Throttle	P. 131
Other Adjustments	P. 132
Adjusting the Brake Lever	P. 132
Adjusting the Rear Suspension	

Importance of Maintenance

Keeping your vehicle well-maintained is absolutely essential to your safety and to protect your investment, obtain maximum performance, avoid breakdowns, and reduce air pollution. Maintenance is the owner's responsibility. Be sure to inspect your vehicle before each ride and perform the periodic checks specified in the Maintenance Schedule. P. 94

AWARNING

Improperly maintaining your vehicle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual. For information about the exhaust emission and noise emission requirements of the U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and the Environment and Climate Change Canada (ECCC). ➡ P. 161

USA

Maintenance, replacement or repair of the emission control devices and systems may be performed by any vehicle repair establishment or individual using parts that are "certified" to EPA standards.

Maintenance Safety

Always read the maintenance instructions before you begin each task and make sure that you have the tools, parts, and skills required. We cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Follow these guidelines when performing maintenance.

- Stop the engine and remove the key.
- Place your vehicle on a firm, level surface using the side stand or a maintenance stand to provide support.
- Allow the engine, muffler, brakes, and other high-temperature parts to cool before servicing as you can get burned.
- Run the engine only when instructed, and do so in a well-ventilated area.

Maintenance Schedule

The maintenance schedule specifies the maintenance requirements necessary to ensure safe, dependable performance, and proper emission control.

Maintenance work should be performed in accordance with Honda's standards and specifications by properly trained and equipped technicians. Your dealer meets all of these requirements. All scheduled maintenance is considered a normal owner operating cost and will be charged to you by your dealer. Keeping an accurate maintenance record will help ensure your vehicle is properly maintained.

Make sure whoever performs the scheduled maintenance completes the maintenance record. Retain all service documents. If you sell your vehicle, these service documents should be transferred with the vehicle to the new owner.

						Frequer	ncy*1				
ltems		× 1,000 mi	0.6	4	8	12	16	20	24	Regular	Refer
		× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4	Replace	to page
Honda Diagnostic System	Х										-
🚯 Fuel Line	\mathbf{N}										-
Throttle Operation	\mathbf{N}										131
Air Cleaner*2						ß			ß		-
Crankcase Breather*3				С	С	С	С	С	С		-
🚯 Spark Plug	Ж						ß				-
Valve Clearance	X										-
Engine Oil			ß		ß		ß		ß	1 Year	-
Engine Oil Filter			ß				ß				-
Engine Idle Speed	\mathbf{N}										-
Radiator Coolant*5										3 Years	121
Cooling System	1										-
Secondary Air Supply System	~										-
Evaporative Emission Control System ^{*4}	1										-

Maintenance Level

 Intermediate. We recommend service by your dealer, unless you have the necessary tools and are

mechanically skilled.

Procedures are provided in an official Honda Service Manual (D P. 167).

✗ : Technical. In the interest of safety, have your vehicle serviced by your dealer.

Emission-Related Maintenance

Emission-Related Items

Maintenance Legend

- II : Inspect (clean, adjust, lubricate, or replace, if necessary)
- L : Lubricate
- R : Replace
- C : Clean

						Freque	ncy*1				
Items		× 1,000 mi	0.6	4	8	12	16	20	24	Regular	Refer to
		× 1,000 km	1.0	6.4	12.8	19.2	25.6	32.0	38.4	Replace	page
Drive Chain			Every 600 mi (1,000 km):							127	
Brake Fluid*5										2 Years	123
Brake Pads Wear					1						124
Brake System											98
Brake Light Switch											125
Headlight Aim											-
Clutch System											128
Side Stand											126
Suspension	1										-
Nuts, Bolts, Fasteners	1										-
Wheels/Tires	*										108
Steering Head Bearings	*										-

Notes:

*1 : At higher odometer reading, repeat at the frequency interval established here.

*2 : Service more frequently when riding in unusually wet or dusty areas.

*3 : Service more frequently when riding in rain or at full throttle.

*4 : 50 STATE (meets California).

*5 : Replacement requires mechanical skill.

Maintenance Record

Distance	Odometer	Date	Performed By:	Notes
600 miles (1,000 km)				
4,000 miles (6,400 km)				
8,000 miles (12,800 km)				
12,000 miles (19,200 km)				
16,000 miles (25,600 km)				
20,000 miles (32,000 km)				
24,000 miles (38,400 km)				
28,000 miles (44,800 km)				
32,000 miles (51,200 km)				
36,000 miles (57,600 km)				
40,000 miles (64,000 km)				
44,000 miles (70,400 km)				
48,000 miles (76,800 km)				
52,000 miles (83,200 km)				
56,000 miles (89,600 km)				
60,000 miles (96,000 km)				
64,000 miles (102,400 km)				
68,000 miles (108,800 km)				

Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A preride inspection is a must, not only for safety, but because having a breakdown, or even a flat tire, can be a major inconvenience.

Check the following items before you get on your vehicle:

- Tire tread wear and air pressures are within limits ≥ P. 108
- Lights, horn, and turn signals operate normally
- Check the condition of the drive chain. Adjust slack and lubricate as needed ⊇ P. 105 Check the following items if you are carrying a passenger or cargo:
- Combined weight is within load limits ▶ P. 133
- Cargo is secured properly
- Suspension is adjusted to suit load ₽ P. 133

Check the following items after you get on your vehicle:

- Throttle action moves smoothly without binding ⊇ P. 131
- Brake lever and pedal operate normally
- Check the fuel level and refuel when needed
 ▶ P. 16, ▶ P. 84
- Engine stop switch functions properly ▶ P. 77

Check the following items at regular intervals:

- Oil level is between the upper and lower level marks ≥ P. 119
- Brake fluid level:

Front: above the LOWER level mark
P. 123
Rear: between the UPPER and LOWER level
marks
P. 123


- Engine coolant level is between the UPPER and LOWER level marks ₽ P. 121
- Side stand functions properly ≥ P. 126

Periodic Checks You should also perform othe maintenance checks at least of regardless of how often you if you ride frequently.	once a month	Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ₽ P. 94				
Tires and wheels		ure (≥ P. 108), examine tread for wear and and check the wheels for damage.				
Fluid levels	Check the engine oil level (≥ P. 119), engine coolant level (≥ P. 121), and brake fluid level (≥ P. 123).					
Lights	Check that the headlight, position lights, brake light, taillight, license plate light, turn signals, and license plate light are working properly.					
Controls	Check the freeplay of the clutch lever (▶ P. 128) and throttle grip (▶ P. 131). Check the front brake lever (▶ P. 132) and rear brake pedal operate properly.					
Drive chain	Check the slack (▶ P. 127), adjust the slack, and lubricate (▶ P. 106) as needed.					
Fuses	,	e a full supply of spare fuses.				
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.					

Always use Honda Genuine Parts or their equivalents to ensure reliability and safety. When ordering colored components, specify the model name, color, and code mentioned on the color label.


Except NX500

The color label is attached to the rear fender under the rear seat. \triangleright P. 115.



NX500

The color label is attached to the rear fender under the seat. \blacksquare P. 116.



AWARNING

Installing non-Honda parts may make your vehicle unsafe and cause a crash in which you can be seriously hurt or killed.

Always use Honda Genuine Parts or equivalents that have been designed and approved for your vehicle.

Battery

Your vehicle has a maintenance-free type battery. You do not have to check the battery electrolyte level or add distilled water. Clean the battery terminals if they become dirty or corroded. Do not remove the battery cap seals. There is no need to remove the cap when charging.



This symbol on the battery means that this product must not be treated as household waste.

NOTICE

An improperly disposed of battery can be harmful to the environment and human health. Always confirm local regulations for proper battery disposal instruction.

What to do in an emergency

If any of the following occur, immediately see your doctor.

- Electrolyte splashes into your eyes:
 - Wash your eyes repeatedly with cool water for at least 15 minutes. Using water under pressure can damage your eyes.

- Electrolyte splashes onto your skin:
 - Remove affected clothing and wash your skin thoroughly using water.
- Electrolyte splashes into your mouth:
 - Rinse mouth thoroughly with water, and do not swallow.

AWARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

Wear protective clothing and a face shield, or have a skilled mechanic do the battery servicing.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds.

Wash your hands after handling.

Cleaning the Battery Terminals

- 1. Remove the battery. ₽ P. 112
- If the terminals are starting to corrode and are coated with a white substance, wash with warm water and wipe clean.
- **3.** If the terminals are heavily corroded, clean and polish the terminals with a wire brush or sandpaper. Wear safety glasses.



4. After cleaning, reinstall the battery. The battery has a limited life span. Consult your dealer about when you should replace the battery. Always replace the battery with another maintenance-free battery of the same type.

Charging

If you use electrical accessories that drain the battery or you do not ride frequently, we recommend that you charge the battery every 30 days using a charger designed specifically for your Honda, which can be purchased from your dealer. Read the information that came with your battery charger and follow the instructions on the battery. Avoid using an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage.

Make sure the ignition switch is in the OFF position before charging the battery.

NOTICE

Improper charging can damage the battery. If you can't charge the battery or it appears unable to hold a charge, contact your dealer.

NOTICE

Jump starting using an automobile battery can damage your vehicle's electrical system and is not recommended. Bump starting is also not recommended.

NOTICE


Installing non-Honda electrical accessories can overload the electrical system, discharging the battery and possibly damaging the system.

Fuses

Fuses protect the electrical circuits on your vehicle. If something electrical on your vehicle stops working, check for and replace any blown fuses.
▶ P. 146

Inspecting and Replacing Fuses

Turn the ignition switch to the OFF position to remove and inspect fuses. If a fuse is blown, replace with a fuse of the same rating. For fuse ratings, see "Specifications." ▶ P. 177



NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

Maintenance Fundamentals

If a fuse fails repeatedly, you likely have an electrical fault. Have your vehicle inspected by your dealer.

Engine Oil

Engine oil consumption varies and oil quality deteriorates according to riding conditions and time elapsed.

Check the engine oil level regularly, and add the recommended engine oil if necessary. Dirty oil or old oil should be changed as soon as possible.


Selecting the Engine Oil

For recommended engine oil, see "Specifications." ≥ P. 176


If you use non-Honda engine oil, check the label to make sure that the oil satisfies all of the following standards:

- JASÕ T 903 standard*1: MA
- SAE standard*2: 10W-30
- API classification*3: SJ or higher

*1. The JASO T 903 standard is an index for engine oils for 4-stroke motorcycle engines. There are two classes: MA and MB. For example, the following label shows the MA classification.



- *2. The SAE standard grades oils by their viscosity.
- *3. The API classification specifies the quality and performance rating of engine oils. Use SJ or higher oils, excluding oils marked as "Energy Conserving" or "Resource Conserving" on the circular API service symbol.



Brake Fluid

Do not add or replace brake fluid, except in an emergency. Use only fresh brake fluid from a sealed container. If you do add fluid, have the brake system serviced by your dealer as soon as possible.

NOTICE

Brake fluid can damage plastic and painted surfaces. Wipe up spills immediately and wash thoroughly.

Recommended brake fluid:

Honda DOT 4 Brake Fluid or equivalent


AWARNING

Clean filler cap before removing. Use only DOT 4 fluid from a sealed container.

Drive Chain

The drive chain must be inspected and lubricated regularly. Inspect the chain more frequently if you often ride on bad roads, ride at high speed, or ride with repeated fast acceleration. ⊇ P. 127 If the chain does not move smoothly, makes strange noises, has damaged rollers, has loose pins, has missing O-rings, or has kinks, have the chain inspected by your dealer.

Also inspect the drive sprocket and driven sprocket. If either has worn or damaged teeth, have the sprocket replaced by your dealer.



NOTICE

Use of a new chain with worn sprockets will cause rapid chain wear.


Cleaning and Lubricating

After inspecting the slack, clean the chain and sprockets while rotating the rear wheel. Use a dry cloth with chain cleaner designed specifically for O-ring chains, or neutral detergent. Use a soft brush if the chain is dirty.

After cleaning, wipe dry and lubricate with the recommended lubricant.

Recommended lubricant:

Pro Honda HP Chain Lube or equivalent



Do not use a steam cleaner, a high pressure cleaner, a wire brush, volatile solvent such as gasoline and benzene, abrasive cleaner, chain cleaner or lubricant NOT designed specifically for O-ring chains as these can damage the rubber O-ring seals. Avoid getting lubricant on the brakes or tires. Avoid applying excess chain lubricant to prevent spray onto your clothes and the vehicle.

Recommended Coolant

Pro Honda HP Coolant is a pre-mixed solution of antifreeze and distilled water.

Concentration:

50% antifreeze and 50% distilled water

A concentration of antifreeze below 40% will not provide proper corrosion and cold temperature protection.

A concentration of up to 60% will provide better protection in colder climates.

NOTICE

Using coolant not specified for aluminum engines or tap/mineral water can cause corrosion.

Crankcase Breather

Service more frequently when riding in rain, at full throttle, or after the vehicle is washed or overturned. Service if the deposit level can be seen in the transparent section of the drain tube.

If the drain tube overflows, the air filter may become contaminated with engine oil, causing poor engine performance.


Tires (Inspecting/Replacing)

Checking the Air Pressure

Visually inspect your tires and use an air pressure gauge to measure the air pressure at least once a month or any time you think the tires look low. Always check air pressure when your tires are cold.

Inspecting for Damage


Inspect the tires for cuts, slits, or cracks that expose fabric or cords, or nails or other foreign objects embedded in the side of the tire or the tread.



Also inspect for any unusual bumps or bulges in the side walls of the tires.


Inspecting for Abnormal Wear

Inspect the tires for signs of abnormal wear on the contact surface.



Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tires immediately. For safe riding, you should replace the tires when the minimum tread depth is reached.



AWARNING

Riding on tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.

Have your tires replaced by your dealer. For recommended tires, air pressure, and minimum tread depth, see "Specifications." ▶ P 176

Follow these guidelines whenever you replace tires.

- Use the recommended tires or their equivalents of the same size, construction, speed rating, and load range.
- Have the wheel balanced with Honda. Genuine balance weights or equivalent after the tire is installed
- Do not install a tube inside a tubeless tire on this vehicle. Excessive heat build-up can cause the tube to burst
- Use only tubeless tires on this vehicle. The rims are designed for tubeless tires, and during hard acceleration or braking, a tubetype tire could slip on the rim and cause the tire to rapidly deflate.

AWARNING

Installing improper tires on your vehicle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

Tire Service Life

The service life of your tires is dependent on many factors, including, but not limited to, riding habits, road conditions, vehicle loading, tire air pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to your regular inspections and maintenance, it is recommended that you have annual inspections performed once the tires reach 5 years old. It is also recommended that all tires be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

The last four digits of the TIN (tire identification number) indicate the date of manufacture.

Tire Identification Number (TIN)

The tire identification number (TIN) is a group of numbers and letters located on the sidewall of the tire.




DOT XXXX XXXX 20 23


DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation.

1 XXXX: Factory code

- 2 XXXX: Tire type code
- (3) 20 23: Date of manufacture (week & year). Example: week 20 in year 23.



Removing & Installing Body Components



Removal

Make sure the ignition switch is in the OFF position.

 Except NX500 Remove the front seat. ➡ P. 114 NX500

Remove the seat. ₽ P. 116

- 2. Unhook the rubber strap from rear side.
- 3. Disconnect the negative ⊖ terminal from the battery.
- **4.** Disconnect the positive ⊕ terminal from the battery.
- **5.** Remove the battery, taking care not to drop the terminal nuts.

Installation

Install the parts in the reverse order of removal. Always connect the positive \oplus terminal first. Make sure bolts and nuts are tight.

Make sure the clock information is correct after the battery is reconnected. ⊇ P. 56 For proper handling of the battery, see "Maintenance Fundamentals." ⊇ P. 101 "Battery Goes Dead." ⊇ P. 144

Clip

Except NX500


Removal

- **1.** Press down on the center pin to release the lock.
- 2. Pull the clip out of the hole.




Installation

1. Push the bottom of the center pin.



- 2. Insert the clip into the hole.
- 3. Press down on the center pin to lock the clip.




Removal

- **1.** Pull the rear corners of the front seat up, then remove the mounting bolts.
- 2. Pull the front seat back and up.

Installation

- 1. Insert the tab into the recess.
- Install and tighten the mounting bolts securely. Make sure that the seat is locked securely in position by pulling it up lightly.



Removal

- 1. Move the seat strap forward.
- 2. Insert the ignition key into the seat lock.
- **3.** Turn the ignition key clockwise, then pull the rear seat forward and up.

Installation


- 1. Insert the tab into the recess.
- 2. Push down on the front of the rear seat while inserting the ignition key into the seat lock.

Make sure that the seat is locked securely in position by pulling it up lightly.

3. Move the seat strap to its original position.

The seat locks automatically when closed.

Removing & Installing Body Components In Seat



Removal


- 1. Insert the ignition key into the seat lock.
- 2. Turn the key clockwise, then pull the seat back and up.

Installation

- **1.** Align the groove of the recess with the tab.
- 2. Insert the front prong into the front stay.
- 3. Insert the rear prongs into the rear stays.
- Push forward and down on the rear of the seat until it locks in place. Make sure that the seat is locked securely in position to pull it up lightly.
 The seat locks automatically when closed.
 Take care not to lock your key in the compartment under the seat.

Left Side Cover

Except NX500



Removal

- 1. Remove the front seat. ₽ P. 114
- 2. Remove the bolt and clip. ₽ P. 113
- **3.** Remove the prongs from the grommets, then remove the left side cover backward by releasing the hooks.

Installation

Install the parts in the reverse order of removal.

NXSOO Hook Grommets Grommet Prongs Bolt Left side cover

Removal

- 1. Remove the seat. ₽ P. 116
- 2. Remove the bolt.
- **3.** Remove the prongs from the grommets, then remove the left side cover backward by releasing the hook.


Installation

Install the parts in the reverse order of removal.

Engine Oil

Checking the Engine Oil

- 1. If the engine is cold, idle the engine for 3 to 5 minutes.
- 2. Turn the ignition switch to the OFF position and wait for 2 to 3 minutes.
- **3.** Place your vehicle in an upright position on a firm, level surface.
- **4.** Check that the oil level is between the upper level and lower level marks on the oil level inspection window.



Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil. ₽ P. 104, ₽ P. 176

- 1. Remove the oil fill cap. Add the recommended oil until it reaches the upper level mark.
 - Place your vehicle in an upright position on a firm, level surface when checking the oil level.
 - Do not overfill above the upper level mark.
 - Make sure no foreign objects enter the oil filler opening.
 - ► Wipe up any spills immediately.

2. Securely reinstall the oil fill cap.

NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil. They may affect lubrication and clutch operation.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals." ▶ P. 104


Coolant

Checking the Coolant

Check the coolant level in the reserve tank while the engine is cold.

- 1. Place your vehicle on a firm, level surface.
- 2. Hold your vehicle in an upright position.
- **3.** Check that the coolant level is between the UPPER level and LOWER level marks on the reserve tank.

If the coolant level is dropping noticeably or the reserve tank is empty, you likely have a serious leak. Have your vehicle inspected by your dealer.



Adding Coolant

If the coolant level is below the LOWER level mark, add the recommended coolant (2 P. 107) until the level reaches the UPPER level mark.

Add fluid only from the reserve tank cap and do not remove the radiator cap.


Coolant Adding Coolant

- 1. Remove the reserve tank cap and add fluid while monitoring the coolant level.
 - Do not overfill above the UPPER level mark.
 - Make sure no foreign objects enter the reserve tank opening.
- 2. Securely reinstall the reserve tank cap.

AWARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, potentially scalding you.

Always let the engine and radiator cool down before removing the radiator cap.



Brakes


Checking Brake Fluid

- **1.** Place your vehicle in an upright position on a firm, level surface.
- Front Check that the brake fluid reservoir is horizontal and that the fluid level is above the LOWER level mark.
 Rear Check that the brake fluid reservoir

is horizontal and that the fluid level is between the LOWER level and UPPER level marks.

If the brake fluid level in either reservoir is below the LOWER level mark or the brake lever and pedal freeplay becomes excessive, inspect the brake pads for wear.

If the brake pads are not worn, you most likely have a leak. Have your vehicle inspected by your dealer.



Inspecting the Brake Pads

Check the condition of the brake pad wear indicators.


The pads need to be replaced if a brake pad is: Front Except NX500 worn to the bottom of the indicator.


Front NX500 worn to the indicator. Rear worn to the indicator.

- Front Except NX500 Inspect the brake pads from in front of the brake caliper.
 Front NX500 Inspect the brake pads from below the brake caliper.
 - Always inspect both left and right brake calipers.
- **2. Rear** Inspect the brake pads from the rear right of the vehicle.

If necessary, have the pads replaced by your dealer.


Always replace both left and right brake pads at the same time.






Adjusting the Brake Light Switch

Check the operation of the brake light switch. Hold the brake light switch and turn the adjusting nut in the direction A if the switch operates too late, or turn the nut in the direction B if the switch operates too soon.



Side Stand

Checking the Side Stand



- Check that the side stand operates smoothly. If the side stand is stiff or squeaky, clean the pivot area and lubricate the pivot bolt with clean grease.
- 2. Check the spring for damage or loss of tension.
- **3.** Sit on the vehicle, shift the transmission to Neutral, and raise the side stand.

- **4.** Start the engine, pull the clutch lever in, and shift the transmission into gear.
- Lower the side stand all the way. The engine should stop as you lower the side stand. If the engine doesn't stop, have your vehicle inspected by your dealer.

Drive Chain

Inspecting the Drive Chain Slack

Check the drive chain slack at several points along the chain. If the slack is not constant at all points, some links may be kinked and binding. Have the chain inspected by your dealer.

- **1.** Shift the transmission to Neutral. Stop the engine.
- 2. Place your vehicle on its side stand on a firm, level surface.
- **3.** Move the lower part of the drive chain up and down to check chain slack, midway between the sprockets.

Drive chain slack:


Except NX500

1 - 1 3/8 in (25 - 35 mm)

NX500

1 3/16 - 1 9/16 in (30 - 40 mm)

► Do not ride your vehicle if the slack exceeds 1 15/16 in (50 mm).



- **4.** Roll the vehicle forward and check that the chain moves smoothly.
- 5. Inspect the sprockets. ₽ P. 105
- 6. Clean and lubricate the drive chain.▶ P. 106

Clutch


Checking the Clutch

Checking the Clutch Lever Freeplay

Check the clutch lever freeplay.

Freeplay at the clutch lever:

3/8 - 13/16 in (10 - 20 mm)



Check the clutch cable for kinks or signs of wear. If necessary, have it replaced by your dealer.

Lubricate the clutch cable with a commercially available cable lubricant to prevent premature wear and corrosion.

NOTICE


Improper freeplay adjustment can cause premature clutch wear.

Adjusting the Clutch Lever Freeplay

Upper Adjustment

Attempt adjustment with the upper clutch cable adjuster first.


- 1. Loosen the upper lock nut.
- 2. Turn the upper clutch cable adjuster until the freeplay is 3/8 13/16 in (10 20 mm).
- **3.** Tighten the upper lock nut and check the freeplay again.



Lower Adjustment

If the upper clutch cable adjuster is threaded out near its limit, or the correct freeplay cannot be obtained, attempt adjustment with the lower clutch cable adjusting nut.

- Loosen the upper lock nut and turn the upper clutch cable adjuster all the way in (to provide maximum freeplay). Tighten the upper lock nut.
- 2. Loosen the lower lock nut.
- **3.** Turn the adjusting nut until the clutch lever freeplay is 3/8 13/16 in (10 20 mm).
- **4.** Tighten the lower lock nut and check the clutch lever freeplay.
- 5. Start the engine, pull the clutch lever in, and shift into gear. Make sure the engine does not stall and the vehicle does not creep. Gradually release the clutch lever and open the throttle. Your vehicle should move smoothly and accelerate gradually.




If proper adjustment cannot be obtained or the clutch does not work correctly, see your dealer.

Checking the Throttle

With the engine off, check that the throttle rotates smoothly from fully closed to fully open in all steering positions and throttle freeplay is correct. If the throttle does not move smoothly or close automatically, or if the cable is damaged, have the vehicle inspected by your dealer.


Freeplay at the throttle grip flange:

1/16 - 1/4 in (2 - 6 mm)



Adjusting the Throttle Freeplay

- 1. Loosen the lock nut.
- 2. Turn the adjuster until the freeplay is 1/16 1/4 in (2 6 mm).
- **3.** Tighten the lock nut, then inspect the throttle action again.



Adjusting the Brake Lever

You can adjust the distance between the brake lever and handle grip.


Adjustment method

Turn the adjuster until the numbers align with the index mark while pushing the lever forward in the desired position.

After adjustment, check that the lever operates correctly before riding.

NOTICE

Do not turn the adjuster beyond its natural limit.



Adjusting the Rear Suspension

AC, II AC, III AC type

Adjusting the suspension requires a pin spanner. We recommend that you have your vehicle serviced by your dealer.


Spring Preload

You can adjust the spring preload by the adjuster to suit the load or the road surface.

CM, II CM, III CM type

Turn the adjuster using the pin spanner and extension bar provided in the tool kit.

Use the pin spanner and extension bar to turn the adjuster. Positions 1 is for a decrease spring preload (soft), or turn the position 3 to 5 increase spring preload (hard). The standard position is 2.



NOTICE

Attempting to adjust directly from 1 to 5 or 5 to 1 may damage the shock absorber.

NOTICE

Do not turn the adjuster beyond its limits.

NOTICE

The rear shock absorber damper unit contains high pressure nitrogen gas. Do not attempt to disassemble, service, or improperly dispose of the damper. See your dealer.

Troubleshooting

Engine Will Not Start	P. 13	35
Overheating (High coolant temperature/ warning indicators are on)	P. 13	36
Warning Indicators On or Flashing	P. 13	37
Low Oil Pressure Indicator	P. 13	37
PGM-FI (Programmed Fuel Injection)		
Malfunction Indicator Lamp (MIL)	P. 13	38
ABS (Anti-lock Brake System) Indicator	P. 13	39
Torque Control Indicator	P. 14	40
Other Warning Indications	P. 14	41
Fuel Gauge Failure Indication		
Coolant Temperature Gauge Failure		
Indication	P. 14	42
Tire Puncture	P. 14	43

Electrical Trouble	P. 144
Battery Goes Dead	P. 144
Burned-out Light Bulb	
Blown Fuse	P. 146

Engine Will Not Start

Starter Motor Operates But Engine Does Not Start

Check the following items:

- Check the correct engine starting sequence. ▶ P. 81
- Check that there is gasoline in the fuel tank.
- Check if the PGM-FI malfunction indicator lamp (MIL) is on.
 - If the indicator lamp is on, contact your dealer as soon as possible.

Starter Motor Does Not Operate

Check the following items:

- Check the correct engine starting sequence. ▶ P. 81
- Check for a blown fuse. ▶ P. 146
- Check for a loose battery connection
 P. 112) or battery terminal corrosion
 P. 101).
- Check the condition of the battery. ▶ P. 144

If the problem continues, have your vehicle inspected by your dealer.

The engine is overheating when the following occurs:

• High coolant temperature indicator and warning indicator come on.

The high coolant temperature indicator is displayed in the warning information.

₽ P. 67, ₽ P. 70

Also the segment H flashes in the coolant temperature gauge. ⊇ P. 66

• Acceleration becomes sluggish. If this occurs, pull safely to the side of the road and perform the following procedure. Extended fast idling may cause the high coolant temperature indicator and warning indicator to come on.

NOTICE

Continuing to ride with an overheated engine can cause serious damage to the engine.

 Stop the engine using the ignition switch, and then turn the ignition switch to the ON position. Check that the radiator fan is operating, and then turn the ignition switch to the OFF position.

If the fan is not operating:

Suspect a fault. Do not start the engine. Transport your vehicle to your dealer.

If the fan is operating:

Allow the engine to cool with the ignition switch in the OFF position.

3. After the engine has cooled, inspect the radiator hose and check if there is a leak.▶ P. 121

If there is a leak:

Do not start the engine. Transport your vehicle to your dealer.

- Check the coolant level in the reserve tank.
 P. 121
 - Add coolant as necessary.
- If 1-4 check normal, you may continue riding, but closely monitor the temperature gauge.

Low Oil Pressure Indicator

If the low oil pressure indicator and the warning indicator come on, pull safely to the side of the road and stop the engine. The low oil pressure indicator is displayed in the warning information. $\square P. 67$, $\square P. 70$

NOTICE

Continuing to ride with low oil pressure can cause serious damage to the engine.

- 2. Start the engine.
 - Only continue riding if the low oil pressure indicator and the warning indicator go off.

Rapid acceleration may momentarily cause the low oil pressure indicator and the warning indicator to come on, especially if the oil is at or near the low level. If the low oil pressure indicator and the warning indicator stay on when the oil level is at the proper level, stop the engine and contact your dealer.

If the engine oil level goes down rapidly, your vehicle may have a leak or another serious problem. Have your vehicle inspected by your dealer.

PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL)

If the indicator comes on while riding, you may have a serious problem with the PGM-FI system. Reduce speed and have your vehicle inspected by your dealer as soon as possible.

ABS (Anti-lock Brake System) Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the ABS. Reduce your speed and have your vehicle inspected by your dealer as soon as possible.

- Indicator comes on or starts flashing while riding.
- Indicator does not come on when the ignition switch is in the ON position.
- Indicator does not go off at speeds above 6 mph (10 km/h).

If the ABS indicator stays on, your brakes will continue to work as a conventional system, but without the anti-locking function.

The ABS indicator may flash if you turn the rear wheel while the rear wheel is lifted off the ground. In this case, turn the ignition switch to the OFF position, and then to the ON position again. The ABS indicator will go off after your speed reaches 19 mph (30 km/h).

Torque Control Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the Torque Control. Reduce your speed and have your vehicle inspected by your dealer as soon as possible.

- Indicator comes and stays on (solid) while riding.
- Indicator does not come on when the ignition switch is turned to the ON position.
- Indicator does not go off at speeds above 3 mph (5 km/h).

Even when the Torque Control indicator is on, your vehicle will have normal riding ability without Torque Control function.


When the indicator comes on while the Torque Control is in operation, you will have to completely close the throttle to regain normal riding ability.


The Torque Control indicator may come on if you rotate the rear wheel while your vehicle is lifted off the ground. In this case, turn the ignition switch to the OFF position, and then to the ON position again. The Torque Control indicator will go off after your speed reaches 3 mph (5 km/h).

Fuel Gauge Failure Indication

If the fuel system has an error, the fuel gauge indicators will be displayed as shown in the illustration.

If these occurs, see your dealer as soon as possible.






Coolant Temperature Gauge Failure Indication

If the cooling system has an error, all segments will blink as shown in the illustration.

If this occurs, see your dealer as soon as possible.



Tire Puncture

Repairing a puncture or removing a wheel requires special tools and technical expertise. We recommend you have this type of service performed by your dealer.

After an emergency repair, always have the tire inspected/replaced by your dealer.

Emergency Repair Using a Tire Repair Kit

If your tire has a minor puncture, you can make an emergency repair using a tubeless tire repair kit.

Follow the instructions provided with the emergency tire repair kit.

Riding your vehicle with a temporary tire repair is very risky. Do not exceed 30 mph (50 km/h). Have the tire replaced by your dealer as soon as possible.

AWARNING

Riding your vehicle with a temporary tire repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tire repair, ride slowly and carefully and do not exceed 30 mph (50 km/h) until the tire is replaced.

Electrical Trouble

Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the vehicle before charging.

Do not use an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage. If the battery does not recover after recharging, contact your dealer.

NOTICE

Jump starting using an automobile battery can damage your vehicle's electrical system and is not recommended.

Bump starting is also not recommended.

Burned-out Light Bulb

Follow the procedure below to replace a burned-out light bulb. Turn the ignition switch to the OFF or LOCK position.

Allow the bulb to cool before replacing it. Do not use bulbs other than those specified. Check the replacement bulb for correct operation before riding.


For the light bulb wattage, see "Specifications." ➡ P. 177

The headlight, brake light, taillight, front turn signals/position lights and rear turn signals use several LEDs.

If there is an LED which is not turned on, see your dealer for servicing.

License Plate Light Bulb

- **1.** Remove the screws, license light cover and license light cover packing.
- 2. Pull out the bulb without turning it.



3. Install a new bulb and reinstall the parts in the reverse order of removal.

Blown Fuse

Before handling fuses, see "Inspecting and Replacing Fuses." ➡ P. 103

Fuse Box Fuses

1. Except NX500

Remove the front seat. **▷** P. 114 **NX500**

Remove the seat. ₽ P. 116


- 2. Remove the fuse box covers.
- **3.** Pull the fuses out one by one with the fuse puller in the tool kit and check for a blown fuse. Always replace a blown fuse with a spare fuse of the same rating.
- 4. Reinstall the fuse box covers.

5. Except NX500


Reinstall the front seat.

NX500

Reinstall the seat.



| Main Fuse



- Remove the left side cover.
 P. 117,

 P. 118
- **2.** Disconnect the wire connector of the starter magnetic switch.

- **3.** Pull the main fuse out and check for a blown fuse. Always replace a blown fuse with a spare fuse of the same rating.
 - Spare main fuse is provided in the starter magnetic switch.
- **4.** Reinstall parts in the reverse order of removal.

NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your vehicle inspected by your dealer.

Information


Keys	. P. 149
Instruments, Controls, & Other Features	P. 150
Caring for Your Vehicle	P. 152
Storing Your Vehicle	. P. 156
Transporting Your Vehicle	P. 157
You & the Environment	P. 157
Vehicle Identification Number	P. 159
Emission Control Systems	P. 161
Catalytic Converter	P. 165
Oxygenated Fuels	P. 166
Authorized Manuals	P. 167
Warranty Coverage and Service	P. 168
Honda Contacts	P. 171
Reporting Safety Defects	P. 173

Keys

Ignition Key

This vehicle has two ignition keys and a key tag with a key number and a bar code. Store the spare key and the key tag in a safe location. To make a duplicate key, take the spare key and the key tag to your dealer or a locksmith. If you lose all ignition keys and the key tag, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.



Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch in the ON position with the engine stopped will drain the battery. Do not turn the key while riding.

Engine Stop Switch

Do not use the engine stop switch except in an emergency. Doing so when riding will cause the engine to suddenly turn off, making riding unsafe.

If you stop the engine using the engine stop switch, turn the ignition switch to the OFF position. Failing to do so will drain the battery.

Odometer

The display remains at 999,999 when the odometer exceeds 999,999.

Tripmeter

Each tripmeter resets to 0.0 when the trip mileage exceeds 9,999.9.

Document Bag

Except NX500

The owner's manual, registration, and insurance information can be stored in the plastic document bag underside of the front seat. ▶ P. 114

NX500

The owner's manual, registration, and insurance information can be stored in the plastic document bag underside of the seat. ₽ P. 116

Ignition Cut-off System

A banking (lean angle) sensor automatically stops the engine and fuel pump if the vehicle falls over. To reset the sensor, you must turn the ignition switch to the OFF position and back to the ON position before the engine can be restarted.

Assist-slipper Clutch System


The assist-slipper clutch system helps to prevent the rear tire from locking up when the deceleration of your vehicle produces a strong engine braking effect. It also makes the clutch lever operation feel lighter.

Use only MA classification engine oil for your vehicle. Using engine oil other than MA classification oil could result in damage to the assist-slipper clutch system.

Automatic Brightness Control

The backlight brightness of the meter will be controlled automatically when "AUTO" is selected on the brightness setting. Ambient brightness is detected by the photosensor.

Do not damage or cover the photosensor. Otherwise, the automatic brightness control may not work properly.



Caring for Your Vehicle

Frequent cleaning and polishing is important to ensure the life of your Honda. A clean vehicle makes it easier to spot potential problems. In particular, seawater and salts used to prevent ice on roads promote the formation of corrosion. Also, mud and dust may accelerate front fork wear and cause oil leaks. Always wash your vehicle thoroughly after riding on coastal, treated roads, muddy or dusty roads.

Washing

Allow the engine, muffler, brakes, and other high-temperature parts to cool before washing.

- 1. Rinse your vehicle thoroughly using a low pressure garden hose to remove loose dirt.
- 2. If necessary, use a sponge or a soft towel with mild cleaner to remove road grime.
 - Clean the windscreen (Except CB500F), headlight lens, panels, and other plastic components with extra care to avoid scratching them.

Avoid directing water into the air cleaner, muffler, and electrical parts.

- **3.** Thoroughly rinse your vehicle with plenty of clean water and dry with a soft, clean cloth.
- **4.** After the vehicle dries, lubricate any moving parts.
 - Make sure that no lubricant spills onto the brakes or tires. Brake discs, pads, drum or shoes contaminated with oil will suffer greatly reduced braking effectiveness and can lead to a crash.
- **5.** Lubricate the drive chain immediately after washing and drying the vehicle.
- 6. Apply a coat of wax to prevent corrosion.
 - Avoid products that contain harsh detergents or chemical solvents. These can damage the metal, paint, and plastic on your vehicle.

Keep the wax clear of the tires and brakes.

If your vehicle has any matte painted parts, do not apply a coat of wax to the matte painted surface.

Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
 - High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
 - Water in the air intake can be drawn into the throttle body and/or enter the air cleaner.
- Do not direct water at the muffler:
 - ► Water in the muffler can prevent starting and causes rust in the muffler.
- ullet Dry the brakes:
 - Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
- Do not direct water under the seat:
 - Water in the under seat compartment can damage your documents and other belongings.

- Do not direct water at the air cleaner:
 - ► Water in the air cleaner can prevent the engine from starting.
- Do not direct water near the headlight:
 - The headlight's inside lens may fog temporarily after washing or while riding in the rain. This does not impact the headlight function.

However, if you see a large amount of water or ice accumulated inside the lens(es), have your vehicle inspected by your dealer.

- Do not use wax or polishing compounds on matte painted surfaces:
 - Use a soft cloth or sponge, plenty of water, and a mild detergent to clean matte painted surfaces. Dry with a soft clean cloth.

Aluminum Components

Aluminum will corrode from contact with dirt, mud, or road salt. Clean aluminum parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.

Panels

Follow these guidelines to prevent scratches and blemishes:

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.
- Avoid getting gasoline, brake fluid, or detergents on the instruments, panels, or headlight.

Windscreen

Except CB500F

Using plenty of water, clean the windscreen with a soft cloth or sponge. (Avoid using detergents or any kind of chemical cleaner on the windscreen.) Dry with a soft, clean cloth.

NOTICE

To avoid possible scratching or other damage, use only water and a soft cloth or sponge to clean the windscreen.

For a dirtier windscreen, use a diluted neutral detergent with a sponge and plenty of water. Make sure to wash off all the detergent. (Detergent residue may cause windscreen cracks.)

Replace the windscreen if scratches cannot be removed and they obstruct clear vision.

Take care to keep battery electrolyte, brake fluid, or other chemical solvents off the windscreen and screen garnish. They will damage the plastic.

Exhaust Pipe and Muffler

The exhaust pipe and muffler are stainless steel but may become stained by mud or dust.

To remove mud or dust, use a wet sponge and a liquid kitchen abrasive, then rinse well with clean water. Dry with chamois or a soft towel.

If necessary, remove heat stains by using a commercially available fine texture compound. Then, rinse by the same manner as removing mud or dust.

If the exhaust pipe and muffler are painted, do not use a commercially available abrasive kitchen cleaning compound. Use a neutral detergent to clean the painted surface on the exhaust pipe and muffler. If you are not sure if your exhaust pipe and muffler are painted, contact your dealer.

NOTICE

Even though the exhaust is made of stainless steel, it can become stained. Remove all marks and blemishes as soon as they are noticed.

Front fork

Mud and dust may accelerate wear on the front forks and cause oil leaks.

To avoid scratching, please handle the forks with the following care.

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.

Storing Your Vehicle

If you store your vehicle outdoors, you should consider using a full-body cover.

If you won't be riding for an extended period, follow these guidelines:

- Wash your vehicle and wax all painted surfaces (except matte painted surfaces).
 Coat chrome pieces with rust-inhibiting oil.
- Lubricate the drive chain. ▶ P. 105
- Place your vehicle on a maintenance stand and position a block so that both tires are off the ground.
- After rain, remove the body cover and allow the vehicle to dry.
- Remove the battery (≥ P. 112) to prevent discharge. Fully charge the battery and then place it in a shaded, well-ventilated area.

After removing your vehicle from storage, inspect all maintenance items required by the Maintenance Schedule.

USA For more information about storage, refer to the *Honda Winter Storage Guide*, available from your dealer.

Canada For more information about storage, visit our website at www.honda.ca and look up "Storage Tips" under the "Honda Warranty" in the Warranty tab for your Model.

Transporting Your Vehicle

If your vehicle needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform and motorcycle tie-down straps. Never try to tow your vehicle with a wheel or wheels on the ground.

NOTICE

Towing your vehicle with a wheel or wheels on the ground can cause serious damage to the transmission.

You & the Environment

Owning and riding a vehicle can be enjoyable, but you must do your part to protect the environment.

Choose Sensible Cleaners

Use a biodegradable detergent when you wash your vehicle. Avoid aerosol spray cleaners that contain chlorofluorocarbons (CFCs) which damage the atmosphere's protective ozone layer.


Recycle Wastes

Put oil and other toxic wastes in approved containers and take them to a recycling center. Call your local or state office of public works or environmental services to find a recycling center in your area and to get instructions on how to dispose of non-recyclable wastes. Do not place used engine oil in the trash or pour it down a drain or on the ground. Used oil, gasoline, coolant, and cleaning solvents contain poisons that can hurt refuse workers and contaminate drinking water, lakes, rivers, and oceans.


Vehicle Identification Number


The VIN and engine serial number uniquely identify your vehicle and are required in order to register your vehicle. They may also be required when ordering replacement parts.

You should record these numbers and keep them in a safe place.



Vehicle Identification Number





Emission Control Systems

Your vehicle engine emits combustion byproducts, including carbon monoxide (CO), oxides of nitrogen (NOx), and hydrocarbons (HC). Gasoline evaporation also emits hydrocarbons. Controlling the production of NOx, CO, and HC is important for the environment.


Exhaust Emission Requirements

The U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB), and Environment and Climate Change Canada (ECCC) require that your vehicle comply with applicable exhaust, crankcase, and fuel permeation emission standards during its useful life, when operated and maintained according to the instructions provided.

CARB also requires that your vehicle comply with applicable evaporative emission requirements during its useful life, when operated and maintained according to the instructions provided.

USA Compliance with the terms of the Distributor's Warranties for Honda Motorcycle Emission Control Systems is necessary in order to maintain a valid emissions system warranty.

The Vehicle Emission Control Information label is located on the left side of the swingarm.



Noise Emission Requirements

The EPA requires that vehicles built after January 1, 1983 comply with applicable noise emission standards for one year or 3,730 miles (6,000 km) after the time of purchase when operated and maintained according to the instructions provided.

Exhaust Emission Control System

The exhaust emission control system includes the following components that should not need adjustment, although periodic inspection by your dealer is recommended.

PGM-FI System

The PGM-FI (programmed fuel injection) system uses sequential multiport fuel injection, and is comprised of air intake, engine control, fuel control, and exhaust control subsystems. The engine control module (ECM) uses sensors to determine how much air enters the engine, and then controls how much fuel to inject.

Ignition Timing Control System

The ignition timing control system adjusts the ignition timing to reduce the amount of HC, CO, and NOx produced.

Secondary Air Injection System

The secondary air injection system adds filtered air into the exhaust gas to help improve emission control performance.

Catalytic Converters

The exhaust system contains one or more catalytic converters. Catalytic converters use a catalyst to convert most of the harmful exhaust gas compounds into harmless compounds.

Evaporative Emission Control System

50 STATE (meets California)

An evaporative emissions control system uses a canister filled with charcoal to adsorb fuel vapor from the fuel tank while the engine is off. The vapor is drawn into the engine and burned while riding.

Crankcase Emissions Control System

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the crankcase breather hose, the air cleaner housing and throttle body.

Fuel Permeation Emission Control

The fuel tank, fuel hoses, and fuel vapor charge hoses use fuel permeation control technologies to prevent fuel vapor emissions. Tampering with these components to reduce or defeat the effectiveness of the fuel permeation technologies is prohibited.

Noise Emission Control System

TAMPERING WITH THE NOISE CONTROL SYSTEM IS PROHIBITED:

U. S. federal law prohibits, and Canadian provincial laws may prohibit, the following acts or the causing thereof: (1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE FOLLOWING ACTS:

- Removal of, or puncturing the muffler, baffles, header pipes or any other component which conducts exhaust gases.
- Removal of, or puncturing of any part of the intake system.
- Lack of proper maintenance.
- Removing or disabling any emissions compliance component, or replacing any compliance component with a noncompliant component.

Problems Affecting Vehicle Exhaust Emissions

Have your vehicle inspected and repaired by your dealer if you experience any of the following symptoms:

- Hard starting or stalling after starting
- Rough idling
- Misfiring or backfiring during acceleration
- Poor engine performance and poor fuel economy

Catalytic Converter

This vehicle is equipped with a three-way catalytic converter. The catalytic converter contains precious metals that serve as catalysts in high temperature chemical reactions that convert hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) in the exhaust gases into safe compounds.

A defective catalytic converter contributes to air pollution and can impair your engine's performance. A replacement unit must be an original Honda part or equivalent. Follow these guidelines to protect your vehicle's catalytic converter:

- Always use unleaded gasoline. Leaded gasoline will damage the catalytic converter.
- Keep the engine in good running condition. A poorly running engine can cause the catalytic converter to overheat, causing damage to the converter or the vehicle.
- If your engine is misfiring, backfiring, stalling, or otherwise not running properly, stop riding and turn off the engine. Have your vehicle serviced as soon as possible.

Oxygenated Fuels

Some conventional fuels blended with alcohol or an ether compound are available in some locales to help reduce emissions to meet clean air standards. These gasolines are collectively referred to as oxygenated fuels. If you plan to use oxygenated fuel, check that it is unleaded and meets the minimum octane rating and blend requirement.

The following fuel blends have been approved for use in your vehicle:

- Ethanol (ethyl alcohol) up to 10% by volume.
 - ► Gasoline containing ethanol may be marketed under the name Gasohol.
- Do not use gasoline containing methanol (methyl alcohol).

If you accidentally fill your fuel tank with an oxygenated fuel containing higher percentages, you may experience performance problems. To resolve the problem, have your dealer drain the fuel tank and replace with the correct fuel. Fuel system or performance problems resulting from the use of an oxygenated fuel containing higher percentages are not covered by your warranty.

NOTICE

Improper use of oxygenated fuels can damage metal, rubber, and plastic parts of your fuel system.

Oxygenated fuel can also damage paint. Damage caused by spilled fuel is not covered by warranty.

If you notice any undesirable operating symptoms or performance problems, try a different brand of gasoline.

Authorized Manuals

USA The Service Manual used by your authorized dealer is available from your Honda dealer or Helm, Inc.

Canada See your dealer to order authorized manuals.

Also available, but not necessary to service your model, is the Honda Common Service Manual, which explains basic service information for various systems on Honda motorcycles, scooters, ATV, and SxS.

USA The Winter Storage Guide in conjunction with the Owner's Manual and Service Manual can help you prepare your Honda motorcycle, scooter, ATV, and SxS for winter storage.

These Honda manuals are written for the professional technician. However, if you possess the proper tools, observe the safety standards, and are mechanically capable, you should find them easy to use.

Special Honda tools are necessary for some procedures.

USA

Order online: www.helminc.com

Order Toll Free: 1-888-CYCLE93

(1-888-292-5393) (NOTE: For Credit Card Orders Only) Monday - Friday 8:00 AM - 6:00 PM ET

Description

2024 CB500F/CBR500R/NX500 Service Manual

Common Service Manual (61CSM00)

USA Winter Storage Guide (S9507)

2024 CB500F/CBR500R/NX500 Owner's Manual

Warranty Coverage and Service

Coverage

Your new Honda is covered by the following warranties:

- Vehicle Limited Warranty
- Emission Control System Warranty
- USA Noise Control Warranty

The responsibilities, restrictions, and exclusions that apply to these warranties are explained in the Warranties Booklet given to you by your Honda dealer at the time of purchase. Always keep your Honda owner's card with your Warranties Booklet.

Canada Please refer to the Warranty Booklet posted on our website at www.honda.ca.

It is important to realize that your warranty applies only to defects in material or workmanship of your Honda. Your warranty coverage does not apply to the normal wear and deterioration associated with use of the vehicle.

Your warranty coverage is not voided if you perform your own maintenance. However, failures that occur due directly to improper maintenance are not covered by these warranties.

USA You can extend almost all of your warranty coverage through the HondaCare® Protection Plan. For more information, see your Honda dealer.

Statement on Warranty Coverage for Aftermarket and Recycled Parts

The Magnuson-Moss Warranty Act, 15 U.S.C. s. 2301 et seq., makes it illegal for motor vehicle manufacturers to void a motor vehicle warranty or deny warranty coverage solely because an aftermarket or recycled part has been used to repair the vehicle or someone other than the authorized service provider performed service on the vehicle. This provision does not apply to a new motor vehicle purchased solely for commercial or industrial use.

Under federal law, a manufacturer may deny warranty coverage and charge for repairs to a vehicle if it is discovered that an aftermarket or recycled part installed on the vehicle is defective or was installed incorrectly and caused damage to another part of the vehicle otherwise covered under warranty. The Federal Trade Commission requires that a manufacturer demonstrate that an aftermarket or recycled part or service performed by a person other than an authorized service provider caused damage to another part of the vehicle otherwise covered under warranty before denying warranty coverage. Additionally, federal law allows a manufacturer to void a motor vehicle warranty or deny warranty coverage if the manufacturer provides the article or service to consumers free of charge under the warranty or the manufacturer has secured a waiver from the Federal Trade Commission.

Service

Please remember that maintenance recommended in the Maintenance Schedule is not included in your warranty coverage.

If you believe you have a problem with your vehicle, call the service department of your Honda dealer. Make an appointment for an inspection and diagnosis. You will be asked to authorize that inspection, and your dealer will return the results of the inspection. If a problem exists and is covered under warranty, your dealer will perform the warranty repairs. If you have any questions about your warranty coverage or the nature of the repair, talk to the Service Manager of your Honda dealer. If a misunderstanding occurs and you aren't satisfied with your dealer's handling of the situation, we suggest you discuss your problem with the appropriate member of the dealership's management team. If you are still not satisfied, contact the owner of the dealership or their designated representative.

Honda Contacts

American Honda Motor Co., Inc.

If you wish to contact Honda directly to comment on your experiences with your vehicle or with your dealer, please send your comments using one of the following methods:

POST MAIL

Powersports Customer Relations American Honda Motor Co., Inc. 4900 Marconi Drive Alpharetta, GA 30005-8847

V PHONE

Telephone: (866) 784-1870

ONLINE CUSTOMER SERVICE

Website: https://powersports.honda.com/ contact-us

Canada

Honda Canada Inc. Customer Relations Department, 180 Honda Boulevard Markham, Ontario L6C 0H9 Telephone: (888) 946-6329 Fax: (877) 939-0909 E-mail: honda_cr@ch.honda.com

Please include the following information in your letter:

- Name, address, and telephone number
- Product model, year, and VIN
- Date of purchase
- Dealer name and address

We will likely ask your Honda dealer to respond, or possibly acknowledge your comments directly.

Your Honda Dealer

The service department of your Honda dealer offers trained personnel to perform regular maintenance and unexpected repairs. It has the latest available service information from Honda and also handles warranty inspections and repairs.

The parts department offers Honda Genuine Parts, Pro Honda products, Honda Accessories (USA only), and Honda accessories and products (Canada only) that provide the same quality that went into your vehicle. **USA** The sales department offers the HondaCare[®] Protection Plan to extend almost all of your warranty coverage.

Your Honda dealer can also supply information about riding events and information about safety training available in your local area.

Reporting Safety Defects

USA

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at: 1-888-327-4236 (TTY: 1-800-424-9153); go to https://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from: https://www.safercar.gov.

Reporting Safety Defects

Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Honda Canada Inc. and you may also inform Transport Canada.

If Transport Canada receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may lead to a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Honda Canada Inc. To contact Transport Canada's Defect Investigations and Recalls Division,

Mailing Address: Transport Canada - ASFAD 330 Sparks Street Ottawa, ON K1A 0N5

Telephone: 819-994-3328 (Ottawa-Gatineau area or internationally) Toll free: 1-800-333-0510 (in Canada)

Online: (English Link:) *www.tc.canada.ca/recalls* (French Link:) *www.tc.canada.ca/rappels*

For more information on reporting safety defects or about motor vehicle safety, go to *https://www.tc.gc.ca/roadsafety*.

Specifications

Main Components

Overall length	Except NX500	81.9 in (2,080) mm)
5	NX500	85.2 in (2,16	5 mm)
	CB500F	31.5 in (800	mm)
Overall width	CBR500R	29.9 in (760	mm)
	NX500	32.7 in (830	mm)
	CB500F	41.7 in (1,060) mm)
Overall height	CBR500R	45.1 in (1,14	5 mm)
	NX500	55.7 in (1,41	5 mm)
Wheelbase	Except NX500	55.5 in (1,410) mm)
	NX500	56.9 in (1,44	5 mm)
Minimum and	CB500F	5.7 in (145 m	ım)
Minimum ground clearance	CBR500R	5.1 in (130 n	าm)
clearance	NX500	7.1 in (180 n	nm)
Caster angle	Except NX	500	25° 30′
Caster angle	NX500		27° 27′
Trail	Except NX	500	4.0 in (101 mm)
ITali	NX500		4.3 in (108 mm)
Curb weight	CB500F		414 lb (188 kg)
	CBR500R		
	AC, II AC,	III AC type	421 lb (191 kg)
	CM, II CM	, III CM type	419 lb (190 kg)
	NX500		432 lb (196 kg)

Maximum weight capacity *1	Except NX500	370 lb (168 kg)	
	NX500	388 lb (176 kg)	
Passenger capacity	Rider and 1	l passenger	
Minimum Annulum	CB500F	8.9 ft (2.70 m)	
Minimum turning radius	CBR500R	9.5 ft (2.90 m)	
Idulus	NX500	7.9 ft (2.40 m)	
Displacement	28.7 cu-in ((471 cm ³)	
Bore x stroke	2.64 x 2.63 in (67.0 x 66.8 mm)		
Compression ratio	10.7:1		
Fuel	Unleaded gasoline Recommended: 86 PON or higher		
Tank capacity	Except NX500	4.52 US gal (17.1 L)	
	NX500	4.62 US gal (17.5 L)	
Battery	YTZ8V or FTZ8V 12 V- 7.0 Ah (10 HR)		
	1st	3.285	
	2nd	2.105	
	3rd	1.600	
Gear ratio	4th	1.300	
	5th	1.150	
	6th	1.043	
Reduction ratio (primary / final)	2.029 / 2.73	33	

*1: Including rider, passenger, all luggage, and accessories

Specifications

Service Data

Service Da			
 .	Front	Except NX500	120/70ZR17M/C (58W)
		NX500	110/80R19M/C 59H
Tire size		Except	160/60ZR17M/C
	Rear	NX500	(69W)
		NX500	160/60R17M/C 69H
Tire type		Radial, tu	ubeless
	Farat	Except NX500	DUNLOP SPORTMAX D222F W
	Front	INASUU	MICHELIN ROAD6
Recommended		NX500	DUNLOP MIXTOUR
Tire		Fuend	DUNLOP SPORTMAX
	Rear	Except NX500	D222 W
			MICHELIN ROAD6
		NX500	DUNLOP MIXTOUR
Tire air pressure	Front	Except NX500	36 psi (250 kPa, 2.50 kgf/cm²)
		NX500	29 psi (200 kPa, 2.00 kgf/cm ²)
		Except	42 psi (290 kPa, 2.90
	Rear	NX500	kgf/cm ²)
	Redi	NX500	36 psi (250 kPa, 2.50
		117200	kgf/cm ²)

Minimum tread	Front	0.06 in (1	1.5 mm)
depth	Rear	0.08 in (2	2.0 mm)
Spark plug	(standard)	CPR8EA-	9 (NGK)
Spark plug gap		0.03 - 0.0	04 in (0.8 - 0.9 mm)
Idle speed	(non- adjustable)	1,200 ± ⁻	100 rpm
Recommended engine oil	except oils resource co service lab standard N	labeled a onserving el, SAE 10 1A, Pro Ho nada) or H	ation SJ or higher s energy conserving or on the circular API W-30, JASO T 903 onda GN4 4-stroke oil donda 4-stroke oil, or cycle oil
Engine oil capacity	After draining	Except NX500	2.6 US qt (2.5 L)
		NX500	2.5 US qt (2.4 L)
	After draining &	Except NX500	2.9 US qt (2.7 L)
	engine oil filter change	NX500	2.7 US qt (2.6 L)
	After disassembly	Except NX500	3.4 US qt (3.2 L)
		NX500	3.3 US qt (3.1 L)
Recommended brake fluid	Honda DO	T 4 Brake	Fluid

Specifications

Cooling system capacity	1.39 US qt (1.32 L)	
Recommended coolant	Pro Honda HP Cool	ant
Recommended drive chain lubricant	Pro Honda HP Chai	n Lube or equivalent
Drive chain slack	Except NX500 1 - 1 3/3	8 in (25 - 35 mm)
	NX500 1 3/16 -	1 9/16 in (30 - 40 mm)
Standard drive	DID520VF or RK520	ELO
chain	No. of links	112
Standard sprocket	Drive sprocket	15T
size	Driven sprocket	41T

Bulbs

Headlight	LED
Brake light/Taillight	LED
Front turn signal/Position light	LED
Rear turn signal	LED
License plate light	12 V-5 W

Fuses

Main fuse		30 A
Other fuse	Except NX500	30 A, 15 A, 10 A, 7.5 A
	NX500	30 A, 15 A, 10 A, 7.5 A, 3 A

Information Record

VIN	
Engine No.	
Color Label & Code	
Owner's Name	
Address	
City/State	
Phone	
Dealer's Name	
Address	
City/State	
Phone	
Service Manager	

WARNING: Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to

www.P65Warnings.ca.gov/passenger-vehicle.





© 2023 Honda Motor Co., Ltd. All Rights Reserved

Printed in the U.S.A.